
Ellis K.Hirst

кр.6-30-05

C17926

rans now has a web site! To get to the web site, ao to: http://www.dot.ca.a



NOTES

I. "R" Panels are to be placed at a maximum of 10 panel segment intervals and at connections to permanent concrete barrier. "R" panels provide for quick and easy placement and removal by lateral movement of panel (No Notched Ends). "N" Panels have concrete notches at each end of the panel. "T" panels have a concrete notch at one end of the panel and a vertical face at the other end of the panel. Notched end connections plus overlapping connection plates require longitudinal movement of the panels during placement or removal. If portable concrete barrier (Type 60K) is to be removed after installation, "R" panels are to be removed first to facilitate removal of the remaining panels.

COLINE

July 1, 2002

elliö k

- 2. Reinforcement and dimensioning details for "R" and "T" Panels are similar to the "N" Panel details shown on Standard Plan A63A.
- 3. Modify end of permanent concrete barrier with the installation of connection plates for connection onnection plates for "R" Panel connection. Where the connection to existing barrier to install height transition, remove existing barrier to end of the height transition.
- 4. All metal plates to be galvanized after fabrication.
- 5. Dimension to bottom of the 732 mm × 57 mm × 19 mm (2811/6" × 21/2" × 3/4") plate.
- 6. The minimum radius of curve for horizontal alignment of portable concrete barrier (Type 60K) is 50 meters (164 feet).
- 7. For additional details of connection plate configurations, see Sections C-C and D-D of Standard Plan A63A.

